



INSTALLATION INSTRUCTIONS:

- 1) FOLD THE DRILLING TEMPLATE AGAINST THE EDGE OF DOOR.
- 2) ALIGN THE CENTERLINE OF THE HANDLE WITH HORIZONTAL CENTERLINE OF FRONT DOOR.
- 3) DRAW DRILLING LINE ON FRONT DOOR AND TOP AND BOTTOM EDGE LINE OF SIDE TEMPLATE ON THE SIDE DOOR.
- 4) DRILL HOLE THROUGH OUT THE DOOR ACCORDING TO TEMPLATE MARKING.
- 5) ALIGN THE SIDE TEMPLATE CENTERLINE WITH ACTUAL CENTERLINE OF DOOR THICKNESS AND DRILL HOLE ACCORDING TO THIS TEMPLATE.
- 6) ALL DIMENSIONS IN MM UNTIL SPECIFIED.